




# Unpacking your homemat




In order to provide the best possible value on delivery and make our products easier to handle, we roll our PVC/vinyl homemats before sending them out to you. As a result, some care and attention is required to return them to their flat working state.

**When you unpack your homemat, please follow the procedure below to get the best results and speed up the time it takes to get your mat totally flat and ready for use.**



Remove your mat from its packaging carton.

Before unrolling your mat leave it to warm through to room temperature.





*\* We recommend wearing gloves while unpacking your chair mat.*



Once your mat is up to normal room temperature, unroll it on to a totally flat and even surface.

It may require two people for initial unrolling.

Do not attempt to unroll your mat on your own if you feel unsure about the procedure.





Now flip your mat over and reverse roll it back up ( in the opposite direction to its original form ).

Unroll your mat once again and place it back down with the embossed side facing upwards and the totally smooth side facing down.




Place flat weighted items, such as books, on to the mat corners and on the central areas.



Your homemat will gradually revert to its flat state, but this could take up to 72 hours depending on the room temperature.

The warmer the room, the quicker it will flatten and be ready for use.



**\*\*** Although your chair mat can be safely used without footwear, care should be taken to avoid catching bare feet on the mat edge.

We recommend that you wear footwear to avoid any unforeseen accidents - and ensure all children and pets are made aware of the mat edges.

**Thank you for choosing a homemat!**